

3 in 1 Fitness Starter Kit USER'S GUIDE

for
WiiFit™



dreamGEAR®
www.dreamgear.net

PACKAGE CONTENTS:

- NeoSleeve
- Mini Massager
- Power Fit
- User's Guide/Warranty Card
- Registration Card

USING THE NEOSLEEVE:

1. Place the NeoSleeve upside down on any flat surface.
2. Place the Wii Balance Board upside down directly on top of the NeoSleeve, aligning the power button hole with the power button on the Wii Balance Board.
3. One at a time, gently stretch each corner of the NeoSleeve over its corresponding balance sensor on the bottom of the Wii Balance Board. Be careful not to rip the NeoSleeve.
4. Carefully smooth out any wrinkles by pulling gently on the outer seam of each corner.

USING THE MINI MASSAGER:

1. Remove the battery cover on the top of the Mini Massager by pushing down on the top and turning in a counter-clockwise direction.
2. Insert 3 "AAA" batteries (sold separately).
3. Replace the battery cover and turn clockwise to lock.
4. Massaging action is activated automatically when pressure is applied to the top of the Mini Massager.

USING THE POWER FIT:

1. Remove the battery door located on the bottom of the Wii Balance Board and insert the Power Fit with the contact points going in first. The hinges will lock into place, indicating proper installation has been completed.
2. Plug the USB power cable into any available USB port on the Wii console. Turn on your Wii Balance Board.
3. To remove, press the release tab and lift the Power Fit up and out.

dreamGEAR®
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net