

2-in-1 Quad Dock Plus

USER'S GUIDE



dreamGEAR[®]
www.dreamgear.net

CONTENTS:

- Quad Dock Plus
- (4) Rechargeable Battery Packs
- 110/240V AC Adapter
- User's Guide
- Warranty Card

GETTING STARTED:

1. Remove all contents from the packaging.
2. Plug the included AC Adapter into the back of the Quad Dock Plus.
3. Insert the included Rechargeable Battery Pack into the battery compartment of the Wii Remote.
4. Insert the Wii Remote with the included Rechargeable Battery Pack connected into the Quad Dock Plus and make contact with the charging terminal. The LED in front will illuminate **RED** indicating that the charge cycle has begun. When the charge cycle is complete, the LED will illuminate **BLUE**.
5. When the charge cycle is complete, simply lift and remove the Wii Remote from the Quad Dock Plus.

TROUBLESHOOTING:

Question: The LED lights are not lighting up.

Answer: Make sure that the AC Adapter is plugged in properly and securely into the Quad Dock Plus.

Question: My Wii Remote is not charging.

Answer:

- Make sure the Rechargeable Battery Pack is inserted into the Wii Remote properly and securely.
- Make sure that the Wii Remote (with Rechargeable Battery Pack connected) is making proper contact with the charging terminals on the Quad Dock Plus.
- Make sure the Quad Dock Plus is free from debris.
- Make sure that the contacts on both the Rechargeable Battery Pack and the Quad Dock Plus are not damaged.

Question: My rechargeable batteries are not charging.

Answer:

- Make sure that the batteries are rechargeable "AA" batteries.
- Make sure that they are properly and securely docked into the Quad Dock Plus.

NOTE: Be sure to keep your Rechargeable Battery Packs and the Quad Dock Plus clean. Dirt and debris harm the battery contacts. Use a dry cloth to clean. DO NOT use water or any chemicals to clean.

dreamGEAR[®]
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net