

PACKAGE CONTENTS:

- NeoSleeve
- User's Guide/Warranty Card
- Registration Card



USING THE NEOSLEEVE:

1. Place the NeoSleeve upside down on any flat surface.
2. Place the Wii Balance Board upside down directly on top of the NeoSleeve, aligning the power button hole with the power button on the Wii Balance Board.
3. One at a time, gently stretch each corner of the NeoSleeve over its corresponding balance sensor on the bottom of the Wii Balance Board. Be careful not to rip the NeoSleeve.
4. Carefully smooth out any wrinkles by pulling gently on the outer seam of each corner.