



dreamGEAR
www.dreamgear.net

Contents

- 1 Rechargeable Battery Pack with USB Charging Cable
- 1 Jeli Sleeve
- 1 Fitness Mat
- 1 Pair of Textured Foot Socks
- 1 Travel Bag

HOW TO USE THE RECHARGEABLE BATTERY PACK

1. Plug the USB Charging Cable into an available USB port on the Wii or any other device that has a powered USB port.
2. Connect the USB Charging Cable to the Rechargeable Battery Pack.
3. The red LED light indicates that the battery is charging.
4. The green LED light indicates that the charge cycle is complete and that the battery is ready for use.
5. Remove the door from the Wii Fit Balance Board and insert the Rechargeable Battery Pack with the “teeth” end going in first. Lock into place with the hinges snapping indicating proper insertion.
6. To remove, press the release tab and lift the Rechargeable Battery Pack up and out.

HOW TO USE THE JELI SLEEVE

Putting Jeli Sleeve on

1. Lay the Wii Fit Balance Board face up on a flat surface.
2. Lift one side of the Wii Fit Balance Board.
3. Slide the Jeli Sleeve over the lifted side of the Wii Fit Balance Board making sure the open slots on the Jeli Sleeve go evenly over the “legs” located on the bottom of the Wii Fit Balance Board. Make sure the silicone pegs on the Jeli Sleeve go flush into the slots located next to the “legs” on the Wii Fit Balance Board. Follow the same procedure on the other side.



NOTE: Make sure that all Jeli pegs are properly inserted into the appropriate peg hole slots. (See picture)

dreamGEAR
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net

Taking the Jeli Sleeve off

1. Lay the Wii Fit Balance Board face down on a flat surface.
2. Lift one side of the Wii Fit Balance Board.
3. From the bottom, lift the Jeli Sleeve from one end removing all of the Jeli pegs from the slots. Lift the Jeli Sleeve over the Wii Fit Board legs and slide it up and over the side of the Wii Fit Balance Board.
4. Follow the same procedure on the other sides and remove the Jeli Sleeve from the Wii Fit Balance Board.

HOW TO USE THE FITNESS MAT

1. Unroll the Fitness Mat; 2. Lay on a flat surface; 3. Start workout.

NOTE: The textured foot socks are meant to be used in conjunction with the Fitness Mat to prevent slippage and to maximize traction.

HOW TO USE THE TRAVEL BAG

1. Lay the Travel Bag flat on the ground.
2. Unzip the Travel Bag by pulling the zippers to the far end of the bag until the zippers can go no further and the bag is completely open and unzipped.
3. Lift open the Travel Bag and slide in the Wii Fit Balance Board.
4. Close the Travel Bag and zip it back up to where the bag is completely closed.

TROUBLESHOOTING

Rechargeable Battery Pack

Problem: The Rechargeable Battery Pack is not charging.

Solution: Make sure ALL the USB cables are properly inserted into the USB ports. Make sure that there is power going to the USB ports.

Problem: The Rechargeable Battery Pack does not go into the Wii Fit Balance Board properly.

Solution: Make sure there aren't broken parts or anything hindering proper insertion.

Problem: What is the charge level of the Rechargeable Battery Pack?

Solution: Click the “home” button on the Wii remote which will bring up the battery level indicator (this solution subject to change).

The Travel Bag

Problem: The zipper does not work properly.

Solution: Make sure there aren't broken parts or anything hindering proper movement of the zipper.