

**Package Contents:**

- Remote & Nunchuck Holsters
- Power Fit
- User's Guide/Warranty Card
- Registration Card



**USING THE REMOTE & NUNCHUCK HOLSTERS:**

1. During exercises or breaks, simply slide your Wii Remote and Nunchuck into their holsters to keep them conveniently within arm's reach.
2. When in use, simply slide the Remote or Nunchuck out of the Holster.

**USING THE POWER FIT:**

1. Plug the USB power cable into an available USB port on your Wii console or any other device that has a powered USB port.
2. Remove the door from the Wii Balance Board and insert the Power Fit with the "teeth" end going in first. Confirm the Power Fit is securely attached to the Wii Balance Board.
3. To remove, press the release tab and lift the Power Fit up and out of the Wii Balance Board.

**TROUBLESHOOTING:**

**Problem:** The Power Fit is not powering my Wii Balance Board.

**Solution:** Make sure that the Power Fit is inserted into the Wii Balance Board properly and securely. Make sure that there is no debris hindering proper placement of the Power Fit.